

Chart of Set Mode for the IC-78

Function	IC-78		IC-78		Note
	Commercial		Marine		
	#01	#02	#03	#04	

Set mode B: (Push and hold down the SET and 2 keys when turning power on)

Mode selection	USB-TX	ON	ON	ON	ON	Inhibit operating mode
	LSB-RX	ON	ON	ON	ON	Transmit will not work when reception is inhibited.
	LSB-TX	ON	ON	ON	ON	
	CW-RX	ON	ON	ON	ON	
	CW-TX	ON	ON	ON	ON	
	RTTY-RX	ON	ON	ON	ON	
	RTTY-TX	ON	ON	ON	ON	
	AM-RX	ON	ON	ON	ON	
	AM-TX	ON	ON	ON	ON	
VFO Mode		ON	ON	OFF	OFF	Allows switchover to VFO mode
Transmit in VFO mode		ON	ON	OFF	OFF	Allows transmit in the VFO mode
Memory write		ON	ON	OFF	OFF	Inhibits memory write operation from key board
Key board operation		ON	ON	ON	ON	Inhibits frequency and memory comment input from keypad
CALL-CH edit		ON	ON	OFF	OFF	Allows rewrite for CALL-CH(CH0)
CALL-CH MODE CHANGE		ON	ON	ON	ON	Mode can be changed after switching to the CALL-CH
TONE CALL switchover		OFF	OFF	ON	ON	Switch to CALL-CH
ALARM TIME		50	50	50	50	1-99sec
PTT TUNE		OFF	OFF	OFF	OFF	Antenna tuner control from the PTT button