

A120 Memory Channel Programming

Important: The ability to write to memory channels must be enabled in the cloning software. The radio's default setting for writing to memory is normally enabled. If this setting is not enabled, open the CS-A120 cloning software, go to **Common Setting > Memory Write** and select **Enable**.

Entering Memory Channels in Groups

1. You must be in VFO mode (**VFO** in the upper left). If not, press the MENU/CLR key and select **VFO MODE**, then press the MHz/GRP (enter) key.
2. Enter your frequency with the arrow keys and press the MENU/CLR key.
3. Select **MEMORY WRITE** with the arrow keys and press the MHz/GRP key.
4. Select **GROUP** with the arrow keys, and press MHz/GRP.
5. Select the group you want to save the frequency into using the arrow keys and press MHz/GRP.
6. Select **WRITE** with the arrow keys and press MHz/GRP.
7. Select **YES** with the arrow keys.
8. Press MHz/GRP to program. **COMPLETED** will appear on the Display.

Selecting Groups and Channels in Groups

1. In VFO mode, momentarily press the MENU/CLR key.
2. Select **MEMORY MODE** with the arrow keys and press MHz/GRP.
3. Momentarily press MHz/GRP.
4. Select **GROUPS** with the arrow keys and press MHz/GRP.
5. Select the group you want to use with the arrow keys.
6. Press MHz/GRP to select the group.
7. Scroll through the channels in that group using the arrow keys.