

A25 Memory Channel Programming

1. Turn on the radio.
2. Press the CLR key.
3. Set your frequency with either the Tuning Dial or enter from the keypad.
4. Press F (Function key) and then quickly press and release the MR/MW key.
5. Verify that **Write** is highlighted and press ENT on the keypad.
6. The Display will show **Write?** Select **YES** with the navigation pad.
7. Press ENT.
8. The Display will show **Completed** and this frequency is now in memory.
9. To verify your entry, press the MR/MW (Memory Recall) key.
10. Rotate the Tuning Dial to scroll through the memories and see your saved frequencies.