

## R30: Writing to a Specific Channel in a Specific Group

**Example:** Writing 145.100 MHz in FM mode into channel 01 in group 55.

1. Press [MW].
2. Rotate the Tuning Dial to select **Write to New CH**, and then press [ENTER].
3. Press [QUICK].
4. Select **Group Select**, and then press [ENTER].
5. Select group **55**, and then press [ENTER].
6. Rotate the Tuning Dial to select channel **01**. The selected channel blinks.
7. Press [MW]. The screen shows **Write to a blank channel?**
8. Select **YES**, and then press [ENTER]. The contents to be written into the channel display briefly, and then are written into channel **01** in group **55**.

