


**A16B Set Mode Features: All Levels**



To Enter Set Mode:  
Press the FUNC key, then immediately press and hold the ENT/SET key until it beeps.

To Select Option for each Feature:  
▲ OR ▼

**Press ENT/SET**  
*To Move Down One Level*

**Press ENT/SET**  
*To Move Down One Level*

**Press ENT/SET**  
*To Move Down One Level*

**Press CLR/HOME**  
*To Move Up One Level at a Time*